



Emerald™ Precision Clean SLA

Emerald Precision Clean SLA is an acidic soak/ultrasonic cleaner that may be used for the removal of a variety of soils and oxides from aluminum, stainless steel, copper, brass, Monel, and other high nickel alloys. Emerald Precision Clean SLA contains a high percentage of “Safer Choice” acceptable surfactants and solubilizers, designed to remove forming lubricants, machining oils, and light rust or scale from these substrates. It is very effective at removing particulate soils from stainless steel and aluminum substrates.

It may be used lime scale removal and the passivation of 300 series stainless steels.

Note: Emerald Precision Clean SLA will not remove heavy scale from stainless steel alloys. When used as recommended will produce little if any etch on most aluminum alloys.

Emerald Precision Clean SLA can be used for part-on-part burnishing and vibratory finishing of copper alloys, stainless steel, steel, Monel, and other substrates.

Features & Benefits

“Safer Choice” approved wetting and solvent system	Contains no mineral acids
Can be used as a burnishing compound	Removes light rust and scales
Non-fuming	Safe

Physical Data

Specific gravity	1.21
Solubility in water	Complete
Appearance and odor	Water white, clear, citrus odor
pH	1.0 – 2.0

Operating Conditions

Temperature	Ambient – 170°F (77°C)
Ventilation	When heated or used in spray



	systems
Equipment	Stainless steel, Polypropylene, Polyethylene, Fiberglass or rubber lined tanks
Heater	Stainless steel or nickel-plated steel piping

Concentration is 5% to 25% (volume) - the dilution will depend upon the soils involved. The rate at which soils, rust, and oxides are removed can be affected by build-up of iron or other metallic salts in the working solutions. This may be compensated for to some extent by increasing the temperature and or the solution concentration.

When used for cleaning aluminum a concentration of 5 to 10% by volume at temperatures up to 170°F with dwell times of 5 to 10 min. is recommended. These parameters will result in little or no etch on most aluminum alloys.

When used as a burnish compound a concentration of 0.2% to 1% by volume is recommend. For the removal of heavier oxides concentration of 5% to 10% by volume may be required.

Note: Processing copper, brass, or bronze parts in the same tank as steel may eventually lead to immersion copper deposits on the steel parts. It is recommended to use a separate tank for cleaning copper and copper-based alloys.

Titration Method

1. Take a 25 mL sample of Emerald Precision Clean SLA solution into a 250 mL Erlenmeyer flask and dilute to 50 mL with water.
2. Add 3 to 5 drops of Phenolphthalein indicator.
3. Titrate to pink endpoint with 1.0 N Sodium Hydroxide solution.
4. Record mL used.

Calculation

$$\text{Concentration} = \text{mL } 1.0 \text{ N NaOH} \times 0.490$$

Test Kit Method

1. Using the syringe provided, place a 0.5 mL sample into sample bottle and fill bottle 1/4 full of water.
2. Add 5 to 10 drops of Phenolphthalein indicator.
3. Add 0.72 N Sodium Hydroxide solution drop wise until solution turns a definite pink.
4. Record the number of drops used.



Calculation

$$\text{Concentration} = \# \text{ Drops } 0.72 \text{ N NaOH} \times 0.60$$

Waste Disposal

Neutralize solutions of Emerald Precision Clean SLA to a pH of 6.0 to 8.0 with either caustic soda or soda ash before discarding. To be completely informed on those latest waste disposal regulations for your area; please contact the local authorities.

Caution

Emerald Precision Clean SLA is an acidic product; avoid skin, eye and oral contact. Wear protective clothing, facemask, chemical goggles and gloves when handling the product and its made-up solutions. Flush exposed areas immediately with copious amounts of clean, cold water. Contact a doctor immediately in case of injury.

WARRANTY: HUBBARD-HALL INC. IS NOT RESPONSIBLE FOR THE MISUSE, MISAPPLICATION, OR MISHANDLING OF THIS PRODUCT. SEE THE TERMS AND CONDITIONS OF SALE ON OUR WEBSITE FOR ADDITIONAL TERMS AND CONDITIONS CONCERNING OUR PRODUCTS, INCLUDING BUT NOT LIMITED TO, LIMITATIONS AND DISCLAIMERS OF WARRANTIES AND LIABILITIES.

Our People. Your Problem Solvers.

For more information on this process,
please call us at 203.756.5521 or email: techservice@hubbardhall.com

Hubbard-Hall holds certifications for **ISO 9001:2015**, Responsible Distribution, as accredited by the **ACD** (Alliance for Chemical Distributors) and as a **Women-Owned Small Business**, as well as maintaining an association with **Omni-Chem**¹³⁶.